



Honda Plug & Play Horn Kit

Thank you for purchasing XTC Power Products Honda Talon Plug & Play Horn Kit.

Please read the instructions fully and familiarize yourself with the components before starting the install. When installing make sure that wires are run away from any hot or moving parts and properly secured.



1. Remove the hood.
2. Install Horn Switch - Using the provided switch template, mark the rectangle for the switch and drill a hole in each corner, using a sharp box knife cut out the rectangle. Push the switch Connector and wires through and attach to switch and install in dash.



3. Install the Power Harness. Next to the Power Steering unit is a blue connector, un-plug the blue connector from the holder by lifting on the small center tab, plug the Power Harness in
4. Mount the Horn, it will be mounted under one of the 3 forward Dash Cover bolts. Prepare the horn by bending the horn bracket with a pair of pliers, remove one of the Dash Cover bolts and slide horn bracket in between the

plastic and the metal tab, reinstall the bolt. Attach the Violet and Black wires to the horn terminals as shown below with the white arrow, terminal color position does not matter.



5. Verify Operation and reinstall Hood.

We can be reached by email at support@xtcpowerproducts.com

XTC Power Products
A Division of XTC Motorsports LLC
925 N McQueen RD. #101
Gilbert AZ 85233
480-558-8588

www.xtcpowerproducts.com

*Disclaimer: This kit is intended for off road use only and XTC Motorsports claims no responsibility for its use. It is up to the purchaser to make sure it complies with all Federal, State and Local laws. R1

Copyright © 2019 XTC MOTORSPORTS LLC, all rights reserved.