

KOLPIN[®] OUTDOORS

Rubber Blade Flap


Product Instructions | Part No: 10-0190

Kit contents:

| Item | Qty | Part Description | Spare PN |
|------|-----|--|--------------------------------|
| 1 | 1 | 72" Rubber Blade Flap | PUR1901 |
| 2 | 11 | Hex Bolt, Zinc Plated, 1/4-20 x 0.75" LG | CYC0967 Hardware Package |
| 3 | 11 | Flat Washer, 1/4" | |
| 4 | 11 | Locknut, Zinc Plated, 1/4-20 | |

Kolpin Blade Installation:

1. Align one end hole of the flap, item #1, with one end hole of the blade on top edge. Use the blade flap as a template, to drill 1/4" diameter holes into your blade where no pre-drilled alignment holes exist. Secure the blade with the provided 1/4" x 3/4" bolts, washers and locknuts. Position the bolts, item #2, as shown, from the topside down thru the flat washers, item #3, and then secure with locknuts, item #4, on underside of top blade edge. Tighten locknuts to apply slight squeeze to rubber and make sure the end of bolt is even with nut bottom or bolt threads extend past the locking portion of locknut.
2. Mark and trim your excess blade flap to proper length of your blade using tin snips or tin shears, as shown.




Note: If any hardware is missing, do not return to the store. Call us to help, Toll Free 1-877-956-5746.



Kolpin Outdoors, Inc. | 9955 59th Ave N | Plymouth, MN 55442

(877) 956-5746 or (763) 478-5800 | www.kolpin.com | customerservice@kolpin.com



Cycle Country / Universal Blade Installation:

1. Use the blade flap as a template, to drill $\frac{1}{4}$ " holes into your blade. Align the flap so that it is centered on the blade. Secure the blade with the provided $\frac{1}{4}$ " x $\frac{3}{4}$ " bolts, washers and locknuts. Position the bolts as shown, from the underside outward, with the flat washers and locknuts on top of the flap. Tighten locknuts to where the top of the nut is even with the end of the bolt.
2. Trim your blade flap to proper length of your blade.

For additional assistance, please contact Kolpin customer service department at (877) 956-5746 or (763) 478-5800 or email customerservice@kolpin.com



One Year Limited Warranty

For the period of one (1) year from the purchase date, Kolpin will replace for the original purchaser, free of charge, any part or parts found upon examination by Kolpin to be defective in material, workmanship, or both.

All transportation costs incurred submitting product to Kolpin for warranty consideration must be borne by the purchaser. If Kolpin determines that the product must be returned to the factory for credit, please call 1-877-956-5746 for a Return Merchandise Authorization (RMA) number and shipping instructions.

This warranty does not apply to parts that have been damaged by accident, alteration, abuse, improper maintenance, normal wear, or other causes beyond the manufacturer's control. In order to protect you and your ATV, certain parts of the plow system and/or hardware are designed to fail when the equipment is over-stressed. Parts that are lost due to loosening and improper maintenance are not covered under warranty. This warranty does not cover removal or reinstallation labor fees of the plow system and related components.

Peripheral products such as engines, electric motors, and actuators may carry an original manufacturer's warranty. Most hardware is general in nature and is easily obtained locally. Be sure to replace with minimum metric class 8.8 specification.

Kolpin Outdoors, Inc.

Telephone: (763)-478-5800

Toll Free: (877)-956-5746

Fax Number: (800)-245-7569

www.kolpin.com

Email: customerservice@kolpin.com